




Pos	Code	Description
0001	70265	HOPPER LID
0002	90391	HOPPER WITH SHUTTER
0003	80119	BOX
0004	85131	GRADUATED DISK
0005	40349	KNOB
0006	70279	SUPPORT
0007	70239	GRIND ADJUSTMENT DISK
0008	45155	MAGNET
0009	50410	DISPLAY BOARD
0010	90442	HEAD ASSEMBLY
0011	90399	INDICATOR
0012	40339	KNOB
0013	85130	SERIGRAPHY
0014	90396	QUICK SET GEAR
0015	90410	BURRS
0016	912087	SCREW
0017	20660	MOTOR PROTECTION
0017	20860	MOTOR PROTECTION
0018	90441	MOTOR ASSEMBLY
0018	90456	MOTOR ASSEMBLY
0019	40319	NUT
0020	746822	WASHER
0021	10471	DRIVE HUB
0022	70275	SPOUT HOLDER
0023	45526	FLAP
0024	90395	SPOUT
0025	50214	REED
0026	50236	THERMOSTAT
0027	70267	COVER
0028	20658	COVER
0028	20858	COVER
0029	20654	CASE
0029	20754	CASE
0029	20854	CASE
0030	50275	SERIAL CONNECTOR
0031	70263	COVER
0032	50276	SERIAL CONNECTOR
0033	50219	CAPACITOR
0034	50108	SWITCH
0035	50412	ELECTRONIC BOARD
0036	75164	SUPPORT
0037	50161	CORD CLAMP
0038	50383	WIRING
0039	75146	PIN
0040	50266	RELAY
0041	20459	METAL PLATE
0042	20657	COVER
0042	20857	COVER
0043	50493	FAN
0044	75206	PIN

Pos	Code	Description
0045	50411	ELECTRONIC BOARD
0046	50153	RELAY
0047	50213	CORD
0047	50225	CORD
0047	50264	CORD
0047	50294	CORD
0047	50295	CORD
0047	50379	CORD
0048	70262	COVER
0049	45323	NUT
0050	90180	SWITCH ASSEMBLY
0051	75205	PIN
0052	90457	MICROSWITCH
0053	20656	PLATE
0053	20856	PLATE
0054	20365	BRACKET
0055	75548	FILTER-HOLDER REST
0056	40246	PIN
0057	70138	FOOT
0058	70335	TRAY